



EVERFURN

# STAGIO ERGO HIGH BACK CHAIR BLACK



---

## INSTRUCTION MANUAL

---

*Please read these instructions carefully and retain them for future reference.*



FD-OC-HB-04.1

## HIGHLIGHTS

- Chair Rotation and Height Adjustable
- Adjustable Armrests to Accommodate Desk Height
- Ergonomic Lumbar and Headrest Support
- Mesh Material
- Rocking Ability

## PACKAGE CONTENTS

- Everfurn Stagio Ergo High-Back Chair Black
- Assembly Parts
- Instruction Manual
















## SPECIFICATIONS

- |                    |                         |
|--------------------|-------------------------|
| • Weight Capacity  | 120 kgs                 |
| • Depth            | 63 cm                   |
| • Height           | 119 – 129 cm            |
| • Width            | 65 cm                   |
| • Surface Material | Mesh & Steel            |
| • Base Material    | Chrome Base             |
| • Caster Type      | Nylon Caster            |
| • Foam Type        | New +Recycle            |
| • Foam Density     | 24 kgs / m <sup>3</sup> |
| • Mechanism        | Butterfly               |
| • Gas Lift Level   | Level 2                 |
| • PU Thickness     | 1.0 mm                  |
| • Base Size        | 320                     |

## SCAN THE QR CODE FOR THE ASSEMBLY VIDEO






# IDENTIFYING PARTS

<b>A</b> 	<b>B</b> 	<b>C</b> 
<b>D</b> 	<b>E</b> 	<b>F</b> 
<b>G</b> 	<b>H</b> 	<b>I</b> 
<b>J</b> 	<b>K</b>  <b>6X25MM</b>	<b>L</b> 
<b>M</b>  <b>6X20MM</b>	<b>N</b> 	<b>O</b>  <b>6X35MM</b>

- A. Back Rest
- B. Seat
- C. Base
- D. Gas Lift
- E. Mechanism
- F. Castor/Wheels x5
- G. Armrest Left
- H. Armrest Right
- I. Allen Key
- J. Screw Caps x6
- K. 6x25 mm Allen Cap Screws x2
- L. Lift Cover
- M. 6x20 mm Allen Cap Screws x4
- N. Head Rest
- O. 6x35 mm Allen Cap Screws x8

**CHAIR ASSEMBLY**

**Important Note:** When tightening any fasteners, ensure not to tighten them more than 90% tightness to prevent damage to the product or the fastener.

 <p>The diagram shows a five-spoke chair base (C). A gas lift (D) is being inserted into the center of the base. A lift cover (L) is shown above the gas lift, with a downward arrow indicating it should be placed over the top of the gas lift. Castors (F) are shown being attached to the ends of the base legs.</p>	<p><b>Step 1:</b></p> <ol style="list-style-type: none"> <li>1. Attach the Castors/Wheels (F) to the Base (C).</li> <li>2. Attach the Gas Lift (D) to the Base (C).</li> <li>3. Cover the Gas Lift (D) with the Lift Cover (L).</li> </ol>
 <p>The diagram shows a seat (B) with a chair mechanism (E) being attached to its underside. An Allen key (I) is shown inserted into the top of the mechanism. Allen cap screws (M) are shown being inserted into the seat to secure the mechanism.</p>	<p><b>Step 2:</b></p> <ol style="list-style-type: none"> <li>1. Attach the Mechanism (E) to the Seat (B) using the 6x20 mm Allen Cap Screws (M) and the Allen Key (I)</li> </ol>
 <p>The diagram shows the chair seat (B) and backrest (A) being assembled. Four Allen cap screws (K) are used to attach the left and right armrests (G and H) to the seat and backrest. Four Allen cap screws (O) are used to attach the headrest (N) to the backrest. Four screw caps (J) are used to cover the screws on the armrests and backrest.</p>	<p><b>Step 3:</b></p> <ol style="list-style-type: none"> <li>1. Attach the Left and Right Armrests (G &amp; H) to the Seat (B) and Back Rest (A) using the 6x35 mm Allen Cap Screws (O) and the Allen Key (I)</li> <li>2. Attach the Headrest (N) to the Backrest (A) using the 6x25 mm Allen Cap Screws (K) and the Allen Key (I).</li> <li>3. Cover the screws with the Screw Caps (J).</li> </ol>



**Step 4:**

1. Attach the assembled seat to the assembled base. Ensure you align the Gas Lift (D) with the Mechanism (E). The seat will clip in place.

**Complete**



## SAFETY PRECAUTIONS

- This product is not intended for commercial use and has only been tested for household use.
- This product is not intended for small children or persons with diminished mental capabilities. Please ensure this product is monitored by a guardian or parent.
- Ensure your hands are dry before touching the plug or power connections.
- CAUTION: Do not remove the panel covers by unscrewing them.
- Refer servicing to qualified service personnel.
- WARNING: Always keep optional accessories, small parts and packaging out of the reach of babies and small children, as these items may pose a choking hazard.


## CLEANING AND CARE INSTRUCTIONS - GENERAL

- **Cleaning:** Wipe down the product's surface using a tickly folded damp cloth.
- **Do not** use harsh or abrasive cleaning chemicals or materials on the product; doing so may damage or scratch the surface finish.
- **Do not** expose the product to direct sunlight or high temperatures for extended periods.
- **Do not** store in temperatures over 60°C.
- Store in a cool, dry place.

## ENVIRONMENTALLY FRIENDLY DISPOSAL

### IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT.

- At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal. It enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.
- Never dispose of used electronics with ordinary solid waste since they contain toxic substances.
- Always dispose of used electronics in accordance with the prevailing community regulations that apply to the disposal of electronics. Please dispose of the device in a waste bin for electric devices.

 <b>WARNING</b>	Lithium-ion Batteries and/or products that contain Lithium-ion Batteries can expose you to chemicals including cobalt lithium nickel oxide, and nickel, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <a href="http://www.P65Warning.ca.gov">www.P65Warning.ca.gov</a> .
--	--



## DISCLAIMER

All product and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.

## WARRANTY

The Everfurn Stagio Ergo High-Back Chair Black include/s a standard 12-month limited warranty against manufacturing defects and faults. Should the product be unboxed with any faulty parts, poor finishing, visible damage, or failure to perform due to a manufacturing defect or poor workmanship, please return it with your proof of purchase (till slip or invoice) to the store of purchase for an exchange, or repair, depending on the store's returns policy.

This warranty commences from the date of purchase.

Kindly retain your proof of purchase and the packaging for your warranty period.

### NOTE:

The warranty does not apply to a product that:

- a. Has failed due to excessive wear and tear beyond reasonable.
- b. Has been misused or neglected.
- c. Has been damaged accidentally or by Force Majeure, including fire and flooding.
- d. Has been used or operated contrary to operating or maintenance instructions outlined in this manual.

The Store of Purchase / Seller cannot accept any returned products that have not been returned in accordance with this warranty or which do not follow their own Returns Policy. Please refer to the Store of Purchase / Sellers Returns Policy for details.

Please contact the store of purchase if you require assistance or have queries about your warranty.